



Setup

Place purifier in a common room with an HVAC return, as far from the return and as high as possible.

Operation

When the unit is on, ionization, electrostatic filtration, and active radiant catalysis (ARC®) are always running.

Use the control panel or remote control to change settings for fan speed and activated oxygen. The fan speed should be set as high as possible without becoming too noisy for your space.

In ARC/Normal Mode, activated oxygen is not being produced.

In High Mode, activated oxygen is scaled for the square footage displayed on the screen. You can adjust the square footage setting to match the total area of your space.

CAUTION: DO NOT exceed your square footage.

In Away Mode, a higher level of activated oxygen is produced for the time set on the screen. Use this setting only when the space will not be occupied.

CAUTION: Away Mode is not for use in spaces occupied by humans or pets. Allow 2 hours following treatment in Away mode prior to re-entering.

Clean

Place purifier in a common room with an HVAC return, as far from the return and as high as possible.

1. Unplug the unit and remove the screw in the rear cover above the power plug.
2. Remove the rear cover by prying the sides loose and tilting up until free.
3. Remove filter assembly by removing the two brass thumbscrews.
4. Disassemble filter, remove dust with running water or vacuum, allowing the filter to dry before reassembly.
5. Remove ARC cell by removing the two black thumb nuts and unplug it from the unit.
6. Do not disassemble ARC cell. Spray it with compressed air or use a vacuum (no liquids).
7. Clean the unit's casing inside and out with a damp cloth or compressed air. If necessary, remove screws at the top of the unit to take off the front grille.
8. Once all components are completely dry, reassemble the unit in reverse.
9. Reconnect the power and hold "Reminder Reset" on control panel until "Perform Cleaning" is no longer displayed.